Candles/SunBeam

Assembly instructions

Please read instructions and watch the two videos (scan the barcode below) before installation In the box: Find the spare parts inside a foam bag please make sure to find it before throwing away the box (glasses, screws, bulb and socket).

Gloves: (inside the black box) please use them while installing the ceiling plate to prevernt fingerprints.

USA: This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

L- CANADA: ce produit doit être installé selon le code d'installation pertinent, par une personne qui connaît bien le produit et son fonctionnement ainsi que les risques inhérents.



Must be installad by a professional electrician!



Turn off correct electrical switch before installation.

1. Start with the ceiling mount. Please open the box and take the fixture out.



2. If your ceiling has a slope make sure you see the tape: 'Lower side' / 'Highest side' and install accordingly.



- 3. Prepare screws according to the type of ceiling: For wood ceilings - please use screws for wood. For drywall ceilings - make sure you put screws where the ceiling joists are and use screws long enough to reach the hard layer on top of the drywall. For concrete - use masonry anchor screws to hold the fixture.
- 4. Screw the metal bracket to the ceiling with the flat side facing up. Twist the GND wire coming out from your electrical box with the GND wire of the Lighting Fixture, Use the twist connector attached to the GND wire of the Lighting Fixture in order to connect between these 2 wires.
- 5. For the next stage please use the gloves supplied in the black box, in order to prevent fingerprints on the canopy. Make sure that the electrical wires are exposed near the bracket. Lift the main canopy and screw it to the bracket using the existing holes at the edge of the bracket. Lift the main canopy and screw it to bracket using the existing holes at the edge of the bracket. You will need a second person to help you hold the fixture up while you connect the electrical wire to the fixture.
- **6.** Connect the positive wire from your electrical box with the positive labeled wire of the Lighting Fixture, Use the twist connector attached to the positive wire of the Lighting Fixture in order to connect between these 2 wires.
- **7.** Connect the negative wire from your electrical box with the negative labeled wire of the lighting fixture >>

- >> use the twist connector attached to the negative wire of the Lighting Fixture in order to connect between these 2 wires. In case the ceiling is not 100% flat, the installer should use white or clear slicone to close the gap between the ceiling & the canopy. If you have the double canopy solution do the same process with the upper canopy and then with the lower canopy.
- 8. Once the canopy is installed, untie the wires, gently stretch them down - go few times on each wire. Insert the bulbs and check they all work.
- **9.** Please remove the bubble wrap from the glass carefully one pack at the time. Each pack contains 2 wide glasses and 2 narrows = one pendant They should be installed equal against each other. Start with the narrow sides.



If you have various color options or pendant's length, make sure you find the note on the glass packs and on the bulb holder - these indicates the right arrangements as the artist designed it. The glasses has two different sides, the more shiny smooth side- is on the outside. The more rough textured glass in from the inside. If you have some white powder on the back side-don't wash it, this is part of the glass texture. If you still have GAP between the glasses please watch again the second video!!

10. After all 4 sides installed - the pendant is not aligned.

Hold the wire about 1" above the pendant and raise the entire unit in folding motion up to 90 degrees. This will prevent the gap between the glasses, Please don't skip this part.



11. Repet this with all the pendants.

12. If you need to adjust the length, for each wire there is a small plastic screw inside the canopy, turn it gently to release the wire, after adjusting close it again. Please be very gentle not to break it.