

SHIMAL'E PELEG

Noy | Noa | Noga

Assembly instructions

In the box:

The glass pendants already attached to the ceiling canopy



Glove (in the black box - please use them while installing the canopy to the bracket)




You will need Edison bulbs led 15W 3000K




*Should be installed by a professional electrician

 **Turn off the correct electrical switch ! before you begin the installation !**

1. Please open the box and take the fixture out leaving the glasses wrapped.



2. Remove the metal bracket from the back of the canopy.



3. Prepare screws according to the type of ceiling:

For wood ceilings please use screws for wood.


For drywall ceilings, make sure you put screws where the ceiling joists are and use screws long enough to reach the hard layer on top of the drywall.



For concrete use masonry anchor screws to hold the fixture.

4. Screw the metal bracket to the ceiling with the flat side facing up.


The earth wire should come out of your electrical box – attach it to the screw on the bracket.



5. For the next stage please use the gloves supplied in the black box, in order to prevent fingerprints on the canopy.

Make sure that the electrical wires are exposed near the bracket.

Lift the main canopy and screw it to the bracket using the existing holes at the edge of the bracket.



You will need a second person to help you hold the fixture up while you connect the electrical wire to the fixture.

If you have the “BOUQUET” arrangement, please hold the wires together under the canopy until you finish installing it to the ceiling.



In case the ceiling is not 100% flat, the installer should use white or clear silicone to close the gap between the ceiling and the canopy.

If you have the double canopy solution do the same process with the upper canopy and then with the lower canopy.



6. Once the canopy is installed, untie the wires, gently stretch them down - go few times on each wire.

7. please remove wrap from the glass cubes and bulb / bulb holder

8. If you need to adjust the length, each cord is being held by a ‘fastener’. Use a plier to gently open it, adjust the length and then gently close it again. Please be very gentle not to break it.

ENJOY!