


Ceiling Fixture instructions



! Turn off the correct electrical switch before you begin the installation.




1. Please Open the box and Unwrap the fixture. There are side glasses attached separately—be careful not to break the glass attached. Keep the glass for the sides of the fixture, on the side until the fixture is installed to the ceiling.




2. Prepare screws according to the type of ceiling: for wood ceilings please use screws for wood. For drywall ceilings, make sure you put screws where the ceiling joists are and use screws long enough to reach the hard layer on top of the drywall. For concrete use masonry anchor screws to hold the fixture.


* Should be installed by a professional electrician



3. Remove the metal bracket from the back of the canopy.




4. Screw the metal bracket to the ceiling with the flat side facing the wall. You must use the existing holes at the edge of the bracket for the screws. ~ Make sure that the electrical wires are exposed near the bracket.



5. You may need a second person to help you hold the fixture up while you connect the electrical wire to the fixture. ~ We recommend using the gloves to hold the fixture for no fingerprints.

It is very important to hold the glass only from the edges of the bigger glass pallet (not from the middle).



6. After connecting the electrical wires connect the fixture to the bracket. Once the fixture is installed, you can attach the glass sides provided.

Turn the light on and enjoy your new art piece!