



MAG Studio



Assembly instructions



! Turn off the correct electrical switch before you begin the installation.




1. Open the box
Unwrap the canopy. Be careful not to break the glass.
While holding the canopy, remove the fixture from the box.




2. Prepare screws according to the type of ceiling: for wood ceilings please use screws for wood. For drywall ceilings, make sure you put screws where the ceiling joists are and use screws long enough to reach the hard layer on top of the drywall. For concrete use masonry anchor screws to hold the fixture.


* Should be installed by a professional electrician



3. Remove the metal bracket from the back of the canopy.



4. Screw the metal bracket to the ceiling with the flat side facing the wall. You must use the existing holes at the edge of the bracket for the screws. ~ Make sure that the electrical wires are exposed near the bracket.



5. You may need a second person to help you hold the fixture up while you connect the electrical wire to the fixture. ~ We recommend using the gloves to hold the fixture for no fingerprints.

Turn the light on and enjoy your new art piece!