

Gleams • Bivalvia Snow • Flakes • Tulip

Assembly Instructions

In the box:

- **Ceiling plate** (look for labels of up/down where there is a slope)
- **Installation kit**
- **Foam bag** contains spare screws, gloves, extra socket, spare glasses





keep the 'installation kit' until you've confirmed all components are present

For USA: This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

For CANADA: ce produit doit être installé selon le code d'installation pertinent, par une personne qui connaît bien le produit et son fonctionnement ainsi que les risques inhérents.


Preparation:

1. Determine your ceiling type (wood, drywall, or concrete) and use the appropriate screws (not provided).
For drywall, locate ceiling joists and make sure the screws go beyond the drywall into the joist.
For concrete, use masonry anchor screws.
2. Be careful when unpacking the fixture. Make sure you have the main fixture, spare parts in a foam bag, and gloves in a black box. Keep the box until you've confirmed that all components are present.


 Before starting installation, Turn off the relevant electrical power source to ensure safety. 

Installation:

1. Detach the metal bracket from the back of the canopy and mount it onto the ceiling, with the flat side upward. Make sure the electrical wires are exposed near the bracket.




If your ceiling is sloped, pay attention to the 'Lower side'/'Higher side' labels.



2. Twist the GND wire coming out of your electrical box with the GND wire of the light fixture. Use the twist connector attached to the GND wire from the bracket. In fixture with LED driver (US/Ca) connect the GND wire from the driver as well.



3. For the next stage you will need a second person to help you hold the fixture up while you connect the electrical wire to the fixture.



Please wear the gloves provided in order to prevent leaving fingerprints on the canopy.

4. Lift the main (or upper if two) canopy and hold it close to the bracket while connecting the wires. Connect the positive (white) and the negative (black) wires from your electrical box with the respective wires from the Fixture. Use the twist connector attached to the wires.
5. Connect the positive and negative wires from your electrical box with the respective wires from the Fixture. Use the twist connector attached to the wires.
6. Carefully position the canopy on to the bracket and fasten it into place using the pre-existing holes.
7. Gently take the glasses protective packaging off.
8. Untie the wires and gently stretch them downwards, repeating the process for each wire. Arrange the wires neatly and plug in the bulbs.

Adjustment :

1. To adjust the wire length, locate the small plastic screw within the canopy corresponding to each wire. Carefully rotate it to free the wire, make the necessary adjustments, and then secure it back in place. Handle with caution to prevent any damage.
2. In case of an uneven ceiling, use white or clear silicone to bridge any space between the ceiling and canopy.
3. If your fixture has a double canopy, repeat the installation process for both the upper and lower canopy.



Maintenance and Care

1. In case you need to change socket consult this video.



you can watch the instructional video by scanning the QR code provided.

2. **Dust:** Use a soft, dry cloth to regularly dust your fixture.

This fixture incorporates an LED G4 2w 170 lumens 3000K).



Always replace with an identical bulb for consistency in performance.

ENJOY!

WhatsApp: +972-52-5279674 • Email: miri@shimale.co.il
www.shimale.co.il • www.etsy.com/shop/shimaleLightArt



SHIMAL'E PELEG
LIGHT IN ART

